



金洋實業有限公司

KAM YEUNG COMPANY LIMITED

Solar Brand Remote Control : Open & Close Curtain Track, Electromagnetic Clutch,
Guaranteed DIY Installation,
Roller Blind, Vertical Blind, Venetian Blind & Skylight Shade

Your Ref :

Our Ref :

Date,

Electronic Remote Control Vertical Blind (New Version)





Motor Installation

- Plug the motor into the big end bracket with 45°.
- The fingers should press the button and turn the motor to a right angle.
- You will hear the sound “**click**” from the button.
- Make sure the button **MUST** fully grip the motor securely.
- One terminal of connection cable should be connected the motor, and other terminal should be connected the control board.





Connection of Power Supply for the System

- Plug the adaptor to the power socket.
- Insert the connector of the adapter to the socket of the motor.

Specification of Wall Mount Control Board (Infrared Receiver)

- Press the buttons on the wall mount control board may control the blind opening or closing directly.
-  button controls the blind closing.
-  button controls the blind opening.
- When the blind fully closed or opened it will stop automatically.
-  button controls the blind to turn left.
-  button controls the blind to turn right.
- When the blind are fully turned left or right, it will stop automatically.
- You may press the micro adjuster by a small sticker to modulate the strength of the motor. For closing and opening of the blind, press **A** with a dot for 3 seconds the light will flash and then press **A** with a dot to add the strength of the motor and press **B** with a dot to reduce the strength of the motor.
- For left turning and right turning of slats, press **B** with a dot for 3 seconds, the light will flash as above. Press **A** with a dot to add the strength of the motor and press **B** with a dot to reduce the strength of the motor.
- Press **A** with a dot or **B** with a dot of the button 50 times to the maximum or minimum point. To the end, there will be the sound **Di-Di-Di**.

Specification of Remote Controller

- 3 pieces of AAA batteries should place in the compartment of the remote controller. Notice the polarity.
- You are able to press the buttons of the remote controller to control the closing or opening of the blind.
-  and  buttons control the closing and opening of the blind.
-  and  buttons control the blind to turn left and right.

Caution : Once you need to connect the power to the motor, please plug the 6 pin cable to 6 pin socket first and then the power pin to the power socket. The action should be gentle and keep the movement in level. On the other hand, if you want to disconnect the power, please unplug the power pin first and then the 6 pin cable. It is because the 6 pin plug and socket are rather delicate. It is easy to cause a short circuit. If the power is there, the transistor may burn out.

Remark: During long periods where the remote controller is not used, remove the batteries to prevent damage from battery leakage.